

LINSAR

The following instructions are for LINSAR LDT1B Digital set top box

Key buttons on the remote control

1. Menu (1) This button gives you access to the functions of the set top box – use the up (4) and down (5) keys to highlight the select the option you want to access and press select (2) - again use the up and down keys to highlight the option in the sub menu and then press select (2)
Guide button (3) – This button is used to access the electronic program guide (EPG) for the digital (Freeview) channels – once you have accessed the EPG you can then use the up and down buttons (4 up – 5 down) to find the channel you want to watch then press OK select (2) to view your selected channel.

If you need to retune your new LINSAR LDT1B

1. Switch on the set top box (Green light should be seen on the front panel)
2. On the left hand side of the screen you will see a list of options – select **INSTALATION** by using the down button (5) then press OK select.
3. The options will change and you will see “first time installation” use the down button (5) to select this option and the press OK select button
4. You will be asked if you want to delete the existing settings answer YES and your set top box will switch off for a moment and then you will be asked which screen type you are using (4:3 is the standard square shape TV and 16:9 is the oblong wide screen TV) Once you have made your selection just answer Yes to the next question and the set top box will go through the tuning process.
Your set top box will now be retuned showing all the channels available (providing you have a good aerial – see below)

PLEASE NOTE

The digital (Freeview) broadcasts are working on reduced power which means that you will need a good aerial to pick up all the available channels – An indoor aerial is usually not sufficient unless you are close to a digital transmitter.

If you are using an indoor aerial there is one thing you can try –

Go through the installation process a laid out above with the television connected to your main rooftop aerial. Once the tuning process has completed reconnect the television to your indoor aerial and try to adjust its position to receive the tuned in channels.

THE FREEVIEW WEB SITE IS AN EXCELLENT INFORMATION SOURCE FOR ALL AERIAL AND GENERAL DIGITAL RECEPTION QUESTIONS – PLEASE SEE

www.freeview.co.uk

